

X-KEY safe

ATTENTION: Please read the operating instructions carefully, before you operate the lock or try to program a new combination of numbers. We cannot accept any liability for problems caused by not following the set up instructions correctly

Please note that your *X-KEY* -safe is delivered with the factory-set code 0 – 0 – 0 and for security reasons, you now need set your own personalised code.

1. OPENING FOR FIRST TIME

- 1.1. Remove the plastic cover from the lock.
- 1.2. Turn the combination lock until the factory-set code 0 – 0 – 0 is level with the opening marks.
- 1.3. Turn the combination lock to the **Left**
- 1.4. Turn the opening handle to the **Right** all the way until it stops.
- 1.5. The safe door is now open

2. SETTING A YOUR NEW CODE

- 2.1. Select your new three-figure code
- 2.2. Use a pen on blunt object to push and hold down the reset button, which I can be found within the recess hole found at the side of the combination lock. **Hold it pushed down until the re set process is completed.**
- 2.3. Now turn the number wheels until your new three-figure code is level to the open marks
- 2.4. Now release the reset button
- 2.5. Your new code is now set
- 2.6. **IMPORTANT** please check you new code works a few times **with the safe door open**

3. OPENING THE X-KEY safe

- 3.1. Turn the combination lock until the code numbers are level to the open marks.
- 3.2. Turn the combination lock left.
- 3.3. Turn the opening handle to the right until it stops.
- 3.4. Safe door is now open.

4. LOCKING THE X-KEY Key-safe

- 4.1. Close the door and turn the rotating handle to the left.
- 4.2. Turn the combination lock to right until it stops.
- 4.3. Scramble the number combination.
- 4.4. Your X-KEY safe is now locked.
- 4.5. Double check the door is locked